

DOGS

UNLIMITED

Make your good dog better.

Included with your nameplate are SWAT RIVETS. These do a neater, stronger job and do not require special tools. Punch or drill a hole in the collar material.

Put the post half of the rivet underneath the collar, layer the nameplate on top of the collar, and top it with the cap.

Start them together with thumb pressure, then place the bottom against a hard surface and swat the top with a hammer.

That's it! You're done!

